Container: C12596532(29" x 8" x 5" @ 34 lbs. )



Page Created: 7/5/2022 10:16:43 AM

#### **UPS GROUND**

Shipping Address:		Download Instructions	医生物胃
Name:	Brock Lourenzo	& Order Details>	1. A. A.
Address 1:	406 1/2 Evergreen Dr		027868
City:	Tillamook	le l	1937 AP
Province:	OR		ieni-ws
Postal Code:	97141-2689	Just take a picture of the above with your	
Country:	US	phone to get your <b>instructions</b> now.	
Phone:	(971) 678-4554		


Bin	Qty	Sku	Dimensions	
C-D8-1-2	1	RA01-003-3-02	29" x 8" x 5" @ 34 lbs.	





# INSTALLATION INSTRUCTIONS

High Clearance Boxed Radius Arms: for Polaris RZR<sup>®</sup> XP 1000



#### Liability Statement

SuperATV's<sup>®</sup> products are designed to best fit user's ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory or aftermarket parts will void any warranty provided by SuperATV<sup>®</sup> and is not recommended. SuperATV's<sup>®</sup> products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV<sup>®</sup> to verify that they will work together.

Although SuperATV® has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc. will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV® urges operators and occupants to wear a helmet and appropriate riding gear at all times.

By purchasing and installing SuperATV<sup>®</sup> products, user agrees that should damages occur, SuperATV<sup>®</sup> will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV<sup>®</sup>, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV<sup>®</sup>. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.

SuperATV® will warranty only parts provided by SuperATV®. Any damage or problems with OEM housings, bearings, seals, or other manufacturers' products will not be covered by SuperATV®. SuperATV® parts and products are not warrantied if item was not installed properly, misused, or modified.

Installing, adding, modifying, or fabricating any factory or aftermarket product to your ATV/UTV may violate certain local, state, and federal laws. Be advised that laws vary depending on town, city, county, state, etc. Use of certain products on public streets, roads, or highways may be in violation law. The Buyer is solely and exclusively legally and personally responsible for any violation of the law by the installation or use of the product. You must abide by all local, state, and federal laws, including but not limited to vehicle safety, traffic laws, and ordinances. It is your responsibility to know the laws and how they apply to you.


The Buyer is responsible to fully understand the capability and limitations of his/her vehicle according to manufacturer specifications, warnings and instructions and agrees to hold SuperATV<sup>®</sup> harmless from any damage resulting from failure to adhere to such specifications, warnings and/ or instructions. The Buyer is also responsible to obey all applicable federal, state, and local laws and ordinances when operating his/her vehicle while using this product, and the Buyer agrees to hold SuperATV<sup>®</sup> harmless from any violation thereof.



Read instructions and view illustrations before beginning.


Thank You For Choosing

Rev IN-RA01-003-3 5/5/2020



- M10 and M12 hardware, Bushings, and Misalignment Bushings are included with kit.

- Use stock RSL bolt to determine M10 or M12 installation.





Misalignment Bushing


Bushing

Keep all stock hardware removed from machine.





### Measure eye-to-eye distances on stock RSL's and transfer dimensions to new RSL's.




- Install (2) Misalignment Bushings into each RSL as shown.




### **Installation:** *passenger side shown.*

- If machine has SuperATV RB-P-RZR1K Rear Bumper use "Install Option A".
- Machines without a Rear Bumper use "Install Option B"; see following page.
- Repeat for opposite side. Tighten hardware completely.



# Install Option B:



## **Radius Arms Adjustment:**

- If Wheels and Axles do not rotate freely, equally adjust Radius Arms "out" in small increments.
- Tighten hardware completely.